



How do I collect a PESTICIDES sample?

Sample Container

- Use a brown glass bottle capable of holding at least 1 L of sample, together with a plastic screw-top cap lined with aluminium foil.
- Container must be clean and free from contaminants.

Label

- Write sample details on the project label supplied and attach it to the bottle.
- A sample submission form is not required.



Collecting the Sample

- Before sampling, rinse the container and aluminium foil with the water to be collected at least once.
- Fill the bottle with the sample.

Transporting Samples to the Laboratory

- Pack the samples into an insulated container together with sufficient freezer bricks to keep the samples cool (2-10°C) during transportation.
- Attach a copy of the FASS address label to the insulated container.
- Dispatch the samples to FASS as soon as possible.



NSW Health Pathology

ABN 49 382 586 535

NSW Forensic & Analytical Science Service

Joseph Street (Weeroona Road entrance), Lidcombe